

Startup Plan

Thursday, October 09, 2008
2:19 PM

- Thursday Evening:
 - Safety system testing once all keys are back.
 - Leave Pbar off overnight
- Friday Day shift:
 - Power outage 7am - 07:40am.
 - Once Power is back
 - Pbar Expert(s) will be in to assist with turn-on.
 - D2 restore
 - Set core vertical trombones to V1=314 ps, V2=342 ps, V3=291 ps.
 - Target Hall puts the blocks back if that doesn't get finished tonight.
 - Run appropriate aggregates to turn the Pbar Source back on after access.
 - Fix everything that fails to turn on.
 - Be in standby until beam is available.
 - Once MI is ready to send us stacking beam
 - Tony Leveling will start out with 2 turns of slip-stacked beam on slow cycle time. Tony will take a good hour to get a precise target sample.
 - Establish stacking and transfers with the help of the Pbar on-call as necessary.