


2005-12-02-Debuncher Admittance Measurement

Friday, December 02, 2005
7:27 AM

11-25-05:

- Establish circulating reverse protons to the Debuncher.
 - Don't forget to take the \$35 out of A:SCRES. If not, beam will be kicked out of the Debuncher on the next \$21 SY120 event.
- From the Pbar Sequencer P64
 - Inject beam and complete a vertical aperture scan
 - Start Pbar FTP #57
 - Red trace is the output of the spectrum analyzer connected to the Debuncher longitudinal Schottky. We use this device to determine the beam extinction point.
 - The Cyan and Green traces are loss monitors. We use these parameters to determine the touch point.
 - The blue trace is Debuncher beam.
 - The FTP has been experiencing problems dropping data. For this reason, we put the plot devices into a 15Hz datalogger. The plot can be retrieved from D44 -> User -> gollwitz -> DebVertAdm. After the scan is complete, do a "T2 = Now" and "Interval = 5 minutes."
 - Run the "Deb Vert aperture scan rev p" aggregate
 - Last 5 commands setup the DEX Bumps
 - Then run from the top
 - Adjust the scraper position to the right side of the plot by hand (~100 Steps = 1 mm) prior to heating the beam




- Print out the scan results and measure the distance between the touch point and the extinction point in mm.
- The equation for calculating the vertical admittance is:

$$A_v = (\text{Measured (mm)} * \text{Scale (mm)} / \text{Plot Length (mm)})^2 / \beta_v$$
 - ◆ Given
 - ◇ Scale = 32mm
 - ◇ Plot Length = 153mm

$$\diamond \beta_v = 13\text{m}$$

$$A_v = (\text{Measurement}(\text{mm}) * 32/153)^2/13$$

- Typical values run around 23 π -mm-mrad.
- Inject beam and complete a horizontal aperture scan
 - Start Pbar FTP #56
 - Red trace is the output of the spectrum analyzer connected to the Debuncher longitudinal Schottky. We use this device to determine the beam extinction point.
 - The Cyan and Green traces are loss monitors. We use these parameters to determine the touch point.
 - The blue trace is Debuncher beam.
 - The FTP has been experiencing problems dropping data. For this reason, we put the plot devices into a 15Hz datalogger. The plot can be retrieved from D44 -> User -> gollwitz -> DebHorAdmit. After the scan is complete, do a "T2 = Now" and "Interval = 5 minutes."
 - Run the "Deb Hor aperture scan rev p" aggregate
 - Last 5 commands setup the DEX Bumps
 - Then run from the top
 - adjust the scraper position to the right side of the plot by hand (~100 Steps = 1 mm) prior to heating the beam



- Print out the scan results and measure the distance between the touch point and the extinction point in mm.
- The equation for calculating the vertical admittance is:

$$A_h = (\text{Measured (mm)} * \text{Scale (mm)}/\text{Plot Length (mm)})^2/\beta_h$$
 - ◆ Given
 - ◇ Scale = 32mm
 - ◇ Plot Length = 153mm
 - ◇ $\beta_h = 11.7\text{m}$
- $A_h = (\text{Measurement}(\text{mm}) * 32/153)^2/13$
- Typical values run around 30 π -mm-mrad.